




# Luxor ZD App

Luxor Splash Screen

Loading/Connecting Screen

Overview Screen

Master Power-off Message Screen  
(Message appears when user presses the non-active power button)







# Group overview screen

## Group Main Screen

## Swipe Right Options

## Gear Screen Options

## Search Screen Pull-down Feature/View






# Group Select & Create Theme Screen

Select Options


Selected Screen View

Confirmation Message Overlay




# Group Add/Detail and Overlay Message Screens

## Group Add/Detail Screen




## Delete Confirmation Screen




# Theme screens


## Theme Main Screen




## Swipe Right Options



## Gear Screen Options




## Theme Add/Detail Screen



# Controller screens


## Controller Main Screen




Active  
Controllers

Not Responding  
Controller(s) with  
message

## Adding Controller Screen




## Controller Information Screen




Future Features

# About the App and Support Screens


## About the App Screen



## Main Support Screen




## Open Accordion Screen



# Assign Lights Screens

## Select Group Screen



## Hold to Assign Screen





## Confirmation Screen





# Luxor ZDC Tablet Home Screen



# Luxor ZD Subpage Menu View

